



3/4" SQUARE DRIVE IMPACT SOCKETS

3/4" METRIC STANDARD/DEEP		3/4" IMPERIAL STANDARD/DEEP		3/4" METRIC 200 mm DEEP		3/4" IMPERIAL 200mm DEEP	
A/F (mm)		A/F (mm)		A/F (mm)		A/F (mm)	
17	40	3/4"	1" 13/16	17	40	3/4"	2"-
18	41	25/32"	1" 7/8	18	41	25/32"	2" 1/16
19	42	13/16"	1" 15/16	19	42	13/16"	2" 1/8
20	44	7/8"	2"-	20	44	7/8"	2" 3/16
21	46	15/16"	2" 1/16	21	46	15/16"	2" 1/4
22	47	31/32"	2" 1/8	22	47	31/32"	2" 5/16
23	48	1"-	2" 3/16	23	48	1"-	2" 3/8
24	50	1" 1/16	2" 1/4	24	50	1" 1/16	2" 7/16
25	52	1" 1/8	2" 5/16	25	52	1" 1/8	2" 1/2
26	53	1" 3/16	2" 3/8	26	53	1" 3/16	2" 9/16
27	54	1" 1/4	2" 7/16	27	54	1" 1/4	2" 5/8
28	55	1" 5/16	2" 1/2	28	55	1" 5/16	2" 11/16-
29	56	1" 3/8	2" 9/16	29	56	1" 3/8	2" 3/4
30	60	1" 7/16	2" 5/8	30	60	1" 7/16	2" 13/16-
31	65	1" 1/2	2" 11/16-	31	65	1" 1/2	2" 7/8
32	70	1" 9/16	2" 3/4	32	70	1" 9/16	2" 15/16
33	75	1" 5/8	2" 13/16-	33	75	1" 5/8	3"-
34	80	1" 11/16	2" 7/8	34	80	1" 11/16	
35	85	1" 3/4	2" 15/16	35	85	1" 3/4	
36	90	1" 13/16	3"-	36	90	1" 13/16	
37	95	1" 7/8		37	95	1" 7/8	
38	100			38	100	1" 15/16	

